


# Deale RECHARGEABLE HEATED BASE LAYER

### **Using the Base Laver**

- 1. To turn ON, press and hold the power button until the LED indicator lights up red.
- 2. Press the power button to change temperature settings.
- 3. Press and hold the power button to turn OFF.
- 4. Remove the batteries.
- 5. Fully charge the batteries before storage.
- 6. Unplug the charger and remove the battery from the garment when not in use:



#### Caution

- 1. Consult your doctor before using the heated base layer if you experience loss of sensation
- 2. Discontinue use when you see redness on the skin. Excessive exposure to heat can lead to burns.
- 3. Only use the supplied charger to charge the device.
- 4. Do not peel or damage the battery's protective film. Damaged batteries can lead to explosion and must be disposed of immediately.
- 5. Do not throw batteries into open fire.
- 6. Dispose of used batteries properly.
- 7. Do not modify the unit or use it for any unintended purpose. Repairs and modifications are only to be carried out by the manufacturer.

# Instructions for Use

# First use and charging the batteries:

- 1. Charge the batteries overnight prior to first use. The LED light on the charger turns GREEN when the batteries are fully charged and ready to use.
- 2. Plug the batteries to the connector in the battery pouch. Secure the batteries in separate compartments of the pouch.

# **Battery Storage and Care**

To ensure a long product life, store the fully charged batteries in a dry environment at room temperature. Detach the batteries from the gloves and charger when not in use.

## **Cleaning the Base Layer**

Machine wash and hand wash are not advisable. Spot cleaning is recommended. You may use a damp cloth or a gentle brush. Never use bleaching or cleaning solvent. Do not iron.

